

Laser Transfer Paper for Light Colored Fabrics for use with Copiers and Printers that do **NOT** use Fuser Oil – Hot Peel Only

ITEMS YOU WILL NEED

- White or light color Cotton, Cotton/Polyester Blend fabric garment. For best results, use fabric with tight weave.
- Heat Press
- Store unused transfer papers in a resealable poly bag in a flat, cool, dry area.

STEP ONE – PRINTING YOUR IMAGE

- 1) Bring paper to room temperature before printing.

This product is intended to work with hotter varieties of Color Laser Copiers and Color Laser Printers.

Bring paper to room temperature before printing.

Print image/design on paper. Be sure to mirror or flip image prior to printing. Always pay close attention to printing.

- 2) Load the sheet into your printer so that it will print on the non-glossy (unlined) side.
- 3) Trim away any unprinted paper around your image that you do not want to transfer.

STEP TWO – TRANSFERRING YOUR IMAGE

HEAT PRESS

- 1) Preheat press to 375° F.
- 2) Press garment for 3-5 seconds to release moisture and remove wrinkles.
- 3) Place printed image face down on the garment (the lined side will be facing up).
- 4) Set at high pressure (60 psi) for best results.
- 5) Press for 20-25 seconds.
- 6) **Wait 3 seconds**, then remove backing paper while still HOT using a smooth, even motion.

WASHING INSTRUCTIONS

- Turn the garment inside out.
- Wash in COLD water.
- Use a mild detergent for best results.
- Do not use bleach or bleach alternative detergents.
- Remove the garment promptly from the washer. The color may bleed if left in the washer.
- Dry on LOW temperature.